



Lighting Control & Design

905 Allen Ave. • Glendale, CA 91201-2019

Ph. (323) 226-0000 • Fax (323) 226-1000 • Support (800) 345-4448

www.lightingcontrols.com

LIGHTING CONTROLS

An AcuityBrands Company


VOLTAGE BARRIER INSTALLATION INSTRUCTIONS

1. If the voltage barrier is attached to the back plate, do not try to force it into the enclosure.
2. First, remove the voltage barrier by removing the 2 screws holding the voltage barrier on the back plate (figure 1).
3. Set the voltage barrier aside.
4. Insert the backplate into the enclosure and secure in place with the screws. Do not proceed to wiring.
5. Now, insert the barrier into the enclosure by tilting it (figure 2).
6. Place the barrier next to the relay, ensuring you are separating the normal powered relays from the emergency powered relays.
7. Reattach the barrier using the screws at the bottom.

Figure 1



Figure 2



Final Product

